

Index

• Numerics & Symbols •

- + character
 - in international phone numbers, 276
 - replacing country code with, 276, 322
- #BAL, 102
- #DATA, 102
- #MIN, 102
- #PMT, 102
- #Warranty Center, 102
- 1X network, 248
- 3G (third generation) network
 - about, 248
 - mobile hotspots in, 252
- 8-megapixel camera, 16

• A •

- abbreviations (texting), 120
- accelerometer, 37
- accessibility settings, 294
- activate
 - Bluetooth, 69, 254
 - locations, 171
 - new phones, 22
 - voice input, 52
 - Wi-Fi, 249
- add
 - address book contacts, 103–107
 - apps to Dock, 284
 - apps to Home screen, 284
 - bookmarks, 146, 147
 - contacts, 80, 103–107
 - contacts to group, 112
 - e-mail attachments, 139
 - events, 221–223
 - layers to Maps, 169–170
 - music, 209–213
 - phone to Google Voice, 95–96
 - shortcut, 285–286
 - social networking accounts, 156–157
 - Wi-Fi network, 251
 - widgets, 285
 - words to dictionary, 315–316

- Add Wi-Fi Network command, 251
- address
 - e-mail, 109, 119
 - street, 171, 174
- address book. *See also* contact(s)
- adding contact images, 108–109
- adding contacts, 103–107
- contact groups, 111–112
- Contacts app, 100–103
- default phone number and e-mail address, 109
- editing contacts, 107–108
- Favorites, 110–111
- overview, 99
- removing contacts, 112–113
- searching contacts, 103
- sharing contacts, 112
- sorting Contacts list, 102–103
- Address box (web page), 144–145
- Airplane mode
 - and making phone calls, 71
 - using, 273–274
- AK Notepad app, 326
- Alarm & Timer app, 224–225
- Albums option (music library), 206
- Aldiko, 226
- alerts
 - about, 25
 - setting, 223
- Alt key
 - accessing symbol characters with, 55
 - locking symbol characters with, 56
- Alt Lock light, 16
- Alternative characters key (sliding keyboard), 53
- Alternative keyboard (Multi-Touch keyboard), 52
- Amazon Kindle, 226–228
- Amazon MP3 app, 211–213
- Amazon.com, 227
- Android Market
 - buying apps, 237–238
 - creating app groups, 242–243
 - finding apps, 235

Android Market (*continued*)

- free apps, 236–237, 325
- games, 231
- managing apps, 238–243
- removing downloaded apps, 240–241
- renting movies, 230
- reviewing downloaded apps, 238–239, 241–242
- sharing apps, 239–240
- shopping, 233–238
- updating apps, 240
- visiting, 234–235

Android operating system

- overview, 26
- sharing information, 149–150
- task management, 318
- updating, 303
- viruses, 329

Android phones, upgrading to Droid 3

- from, 12
- animated wallpaper
 - changing Home screen to, 282
 - touching Home screen with, 40
 - traditional versus, 282–283

App menu

- defined, 45
- reviewing most recently used, 47
- starting apps from, 45–46

App menu groups, 242–243

appearance (web pages), 153

application icon, 39

appointments

- adding events, 221–223
- browsing dates, 218–220
- Google Calendar, 218
- overview, 217–218
- reviewing schedule, 220–221

apps (applications). *See also* Android

- Market; *specific apps*
- bar code for installing, 3
- defined, 4
- e-mail, 128
- locating, 46
- number of, 217
- paying for, 237
- preinstalled, 241
- ratings, 235
- recommended, 325–329

- starting, 44–46
- troubleshooting, 306
- web browsing versus, 144
- apps groups, 242
- arrow keys, 320
- Artist option (music library), 206
- attachments
 - e-mail, 138–139
 - Gmail indicator for, 132
 - media files, 203
 - multimedia messages, 123, 125
- AutoAnswer, 291–292
- AutoPlay dialog boxes, 261
- AutoRetry, 291–292



Back button (web browsing), 146

Backspace key

- on Multi-Touch keyboard, 51
- on sliding keyboard, 53

backup, 302–303

Backup Assistant

- in setup process, 23
- using, 303

bar codes, 3

bar codes scanner apps, 326

battery

- charging, 13–14
- determining power-consuming activities, 297–298
- importance of, 295
- installing, 12–13
- largest power consumers, 321
- managing power consumption, 298–299
- monitoring, 296–297
- in original package, 10
- prolonging life of, 299–301
- replacing, 301
- status, 297–298
- troubleshooting, 308
- turning on phone, 22
- battery cover, 16
- Blockbuster app, 231
- Bluetooth
 - activating, 69, 254
 - in Airplane mode, 273
 - defined, 253

- headset, 18, 71, 76
 - overview, 253–255
 - power consumed by, 321
 - turning off, 300
 - using headset, 254–255
- Bluetooth printer, 256–257
- bookmark(s)
 - for Google account page, 27
 - opening, 148
 - web browsing, 146–148
- Bookmark button, 145
- Books app
 - in Android Market, 234
 - using, 226–227
- brightness, changing, 292
- Browser app, 144. *See also* web browsing
- Browsing history (web browsing)
 - in Browser program, 147
 - clearing, 146
- businesses, finding, 174–175



- Calculator app, 223
- Calendar app
 - adding events, 221–223
 - browsing dates, 218–220
 - colors and event categories, 220
 - reviewing schedule, 220–221
- Calendar widget, 218
- call(s). *See also specific topics*
 - conference, 69, 84–85
 - dialing, 72–73
 - to displayed contacts, 101
 - Favorites list, 74
 - forwarding, 85–86
 - incoming signal volume, 77–78
 - missed, 78
 - placing, 68–71
 - receiving, 74–76, 83–84
 - Recent Calls list, 73–74
 - reviewing, 79–80
 - ringtones, 87–89
 - sending to voice mail, 86–87
 - signal strength, 72
 - Switch Calls, 84
 - Text Message Reply, 76–77
 - Voice command for, 63

- Call Connect, 292
- Call duration, 69
- call forwarding
 - overview, 85–86
 - to voice mail, 86–87
- Call in Progress notification
 - in Dialer app, 69
 - function of, 71
- Call Voice Mail button, 92
- Camcorder app
 - overview, 187
 - recording video, 188
 - video quality, 189
- Camera app
 - on Dock, 284
 - taking pictures with, 182–186
- Camera Roll
 - function of, 194
 - viewing, 195
- cameras
 - adjusting, 187
 - changing resolution, 184–185
 - deleting images, 183–184
 - front-facing, 190
 - location of, 15–16
 - panorama shots, 185–185
 - recording video, 187–189
 - self-portrait, 185
 - setting flash, 184
 - setting image location, 186–187
 - setting video quality, 189–190
 - taking pictures, 182–183
 - Video Message mode, 190–191
 - zoom function, 17
- capital letters (sliding keyboard), 55
- Caps Lock, 55
- Caps Lock light, 51
- car cell phone charger
 - as accessory, 19
 - using, 14
- Car Home screen, 41–42
- CardStar app, 326–327
- carrier voice mail
 - overview, 91–92
 - retrieving messages, 92–93
 - setting up, 92
- carrying cases, 20
- carrying the phone, 19–20

- CDMA (Code Division Multiple Access), 279
- cell phone locator services, 317
- cellular data network, 248
- cellular service
 - provider of, 3
 - and text messaging charges, 118
- censor feature
 - disabling, 315
 - for voice commands, 64
- Charge Only option (USB connection), 261
- charger/data cable, 10
- charger head, 10
- charging battery
 - procedure, 13–14
 - storing phone while, 20
 - from wall socket vs. computer, 297
- checkbox icon
 - and disabling/enabling options, 301
 - for phone options, 3
- cleaning phone, 302
- Clear Form Data, 154
- Code Division Multiple Access (CDMA), 279
- commands, voice, 63–64
- Compass app, 170
- Compass Pointer (Maps app)
 - and Perspective view, 169
 - and phone's direction, 170
- computer
 - adding music from, 209–211
 - connecting phone with, 259–260
 - importing contacts from, 105–106
- conference calls
 - Add call button for, 69
 - procedure for making, 84–85
- Connected screen
 - components of, 69
 - returning to, 70
- connection. *See also* wireless connection
 - checking, 305
 - to other media devices, 267–269
 - USB, 259–262
 - Wi-Fi, 251
- contact(s)
 - adding, 80, 103–107
 - adding images, 108–109
 - adding in Maps app, 106–107, 175
 - dialing, 72–73
 - editing, 107–108
 - favorite, 110–111
 - grouping, 111–112
 - locating with Maps app, 176
 - removing, 112–113
 - setting image for, 201–202
 - setting ringtones for, 88
 - sharing, 112
 - sorting, 102–103
 - sources of information on, 102
 - starting new e-mail message from, 137
 - taking pictures of, 322–323
- contact groups, 111–112
- Contact tag, 199
- Contacts app, 100–103
- Contacts list, 102–103
- cookies, clearing, 154
- Copy Media, 269
- copying text, 61–62
- cropping images, 200
- cursor
 - moving, to edit text, 58
 - and Shift key, 55
 - and typing on Droid 3, 54
- Custom Saver mode, 299
- customer service (Verizon), 278
- customization. *See also* personalization
 - e-mail, 139–141
 - phone, 281
- cutting text, 61–62



- Data Saver, 301
- dates, browsing, 218–220
- Day view (Calendar), 218–220
- default
 - e-mail account, 141
 - phone number and e-mail address, 109
- Default Ringtone, 88
- Del key, 54
- delete. *See also* remove
 - alarms, 225
 - bookmarks, 147
 - contacts from group, 112
 - e-mail, 134, 140–141
 - images, 183–184, 202
 - music, 215
 - pictures, 183–184
 - songs from playlist, 215
 - text messages, 125

- Dialer app
 - on Dock, 284
 - location on Home screen, 39
 - using, 68
 - dialing calls
 - international, 71, 275–276, 279
 - overview, 72–73
 - from Recent Calls list, 73–74
 - speed dial, 82
 - dialpad, 22
 - Dictate address (web browsing), 145
 - dictating to phone
 - sensor feature, 64
 - overview, 62–63
 - steps for, 315
 - text messages, 119
 - voice commands, 63–64
 - Dictation key, 53
 - dictionary, adding words to, 315–316
 - DIF setting (video quality), 189
 - Digital Living Networking Alliance (DNLA)
 - devices, 268–269
 - digital network, 248
 - digital zoom, 183
 - direct-dial shortcuts, 316
 - direction keys
 - moving cursor with, 58
 - on sliding keyboard, 53
 - direction of phone. *See* orientation
 - directions (Maps app), 175–177
 - disconnection
 - audio alert for, 71
 - from computer, 262
 - Display symbols palette, 53
 - DNLA (Digital Living Networking Alliance)
 - devices, 268–269
 - Dock
 - adding apps to, 284
 - dragging icons, 287
 - on Home screen, 39
 - Dolphin Browser, 327
 - Done key
 - function, 52
 - on Multi-Touch keyboard, 51
 - in setup process, 23
 - Double Tap Home Launch function
 - and double-tap method, 35
 - setting, 293
 - double-tap technique, 35
 - doubleTwist
 - function of, 211
 - using, 263–264
 - Download Complete icon, 151
 - downloading
 - from Android Market, 234–236
 - from web, 150–152, 212
 - Downloads app, 266
 - Downloads screen, 152
 - dropped calls, alert for, 71
 - DVD setting (video quality), 189
- E •
- e-book, 225
 - e-book reader apps
 - Amazon Kindle, 226–228
 - Google Books, 226–227
 - overview, 225–226
 - e-mail
 - in Airplane mode, 273
 - apps for, 128
 - attachments, 138–139, 191
 - checking Gmail inbox, 131–132
 - composing, 135–137
 - to displayed contacts, 101
 - getting messages, 131
 - importing contacts from, 105
 - manual delete option, 140–141
 - overview, 127
 - reading messages, 133–135
 - replying, 134–135
 - signature, 54, 139–140
 - text messages versus, 122
 - universal inbox, 132–133
 - e-mail account. *See also* Gmail
 - ISP, 129–130
 - setting default, 141
 - web-based, 128–129
 - e-mail address
 - default, 109
 - in text message, 119
 - earbud-style earphones
 - storing, 18
 - using, 17–18
 - earphones, 17–18
 - Bluetooth, 255
 - locking phone when using, 70

Edit Text menu, 60
 editing. *See also* text editing
 contacts, 107–108
 images, 200–202
 Effects adjustment (camera), 187
 8-megapixel camera, 16
 Email app. *See also* Gmail
 customizing, 139–141
 getting messages, 131
 reading messages, 133–135
 replying, 134–135
 setting up accounts, 128–130
 universal inbox, 132–133
 Emergency Call button, 26
 emergency calls, 26
 End Block marker, 59
 End Call button
 function of, 70
 and juggling two phone calls, 84
 location of, 69
 Enter key
 on Multi-Touch keyboard, 51
 on sliding keyboard, 53
 Erase key
 on Multi-Touch keyboard, 51
 on sliding keyboard, 53
 events
 adding, 221–223
 details of, 220–221
 external speaker, 16



face tag, 199
 Facebook, 158–162
 Facebook for Android app
 on menu for sharing, 203
 using, 161–162
 Favorites list
 address book, 110–111
 calls, 74
 wireless printer, 257
 FBReader, 226
 features, 14–17
 files, downloading, 151
 Files app, 266–267

flash
 location of, 16
 for recording video, 191
 setting, 184
 Force Stop button, 241
 Forward button (web browsing), 146
 forwarding
 calls, 85–87
 e-mail, 134
 text messages, 121–122
 free apps
 from Android Market, 236–237
 Internet radio, 215–216
 recommended, 325–329
 front-facing camera
 location of, 15
 videotaping with, 190



Gallery app
 creating new album, 196–197
 deleting images, 202
 finding image location on map, 199
 HDMI option, 268
 overview, 194–195
 picture editing, 200–202
 for pictures, 183
 printing pictures, 200
 tagging images, 197–198
 uploading images, 160, 162–163
 for video, 189
 viewing albums in library, 195–196
 games, 231
 Genres option (music library), 206
 Geo-Tag, 186
 Gesture Search app, 327
 global positioning system (GPS)
 finding your location with, 171
 and Maps app, 168
 Global System for Mobile Communications (GSM), 279
 gloves, 36
 Gmail
 checking inbox, 131–132
 contacts removed from, 113
 creating new contacts with, 105
 deleting mail, 141

- overview, 128
- Save Draft button, 137
- Sent messages, 137
- signature for, 139
- voice mail transcripts, 97
- Go button (web browsing), 145
- Go key
 - function of, 52
 - on Multi-Touch keyboard, 51
- Google, 26
- Google account
 - advantages of, 4, 27
 - backup, 302–303
 - coordinating phone with, 22
 - creating, 27
 - setting up, 28–29
 - storing contacts in, 104
 - syncing with, 27
- Google Books, 226–227
- Google Buzz, 163
- Google Calendar, 218
- Google Checkout, 238
- Google Finance app, 327–328
- Google Labs, 170
- Google location services, 171
- Google Mobile search page, 153
- Google Search widget, 148–149
- Google Sky Map app, 328
- Google Talk, 126
- Google Voice
 - adding phone to, 95–96
 - and call forwarding, 86
 - overview, 94–95
 - retrieving messages, 96–97
 - setting up, 95
- GPS (global positioning system)
 - finding your location with, 171
 - and Maps app, 168
- groups
 - apps, 242
 - contact, 111–112
- GSM (Global System for Mobile Communications), 279
- Guided Tours
 - getting help from, 304
 - and setup process, 23
- 
- hands-free headset, 17–18
- HD+ setting (video quality), 189
- HDMI cable
 - as accessory, 19
 - location, 15
 - and projecting media, 267–268
- HDMI viewing options, 268
- headphone jack, 15
- headset, 17–18
 - Bluetooth, 18, 69, 71, 76, 254–255
 - hands-free, 17–18
- heat, 20
- help, 304
- Help Center app, 304
- hibernation (Sleep mode)
 - about, 26
 - activating, 30–31
- high definition setting (video quality), 189
- History list (web browsing)
 - in Browser program, 147
 - clearing, 146
- Home button, 70
- home page
 - blank, 153
 - Google, 145
 - web browsing, 144–145, 152–153
- Home screen
 - adding apps, 284
 - apps shortcuts, 237
 - bookmarked websites on, 147
 - Car Home, 41–42
 - creating shortcuts, 285–286
 - defined, 25
 - features, 38–40
 - navigation shortcut on, 178–179
 - personalizing, 282–287
 - rearranging/removing icons and widgets, 286–287
 - reviewing notifications, 42–44
 - starting applications, 44
 - using widgets, 45
 - viewing all panels, 40–41
 - wallpaper, 282–283
 - widgets, 285
- hotspot, mobile wireless, 252
- human engineering, 153

• I •

I-Dial, 275
 icons, rearranging and removing, 286–287
 images. *See also* photo album; picture(s)
 for contacts, 108–109
 downloading from web, 151
 editing, 200–201
 finding location on map, 199
 sharing, 202–203
 storage locations, 183
 tagging, 197–198
 In-Pocket Detection, 313–314
 information about phone, 303
 installing battery, 12–13
 instructions, 10
 international calling
 dialing international numbers,
 71, 275–276
 from overseas, 278–279
 with Skype Mobile, 276–279
 using + key in, 276, 322
 Internet connection, tethering, 253
 Internet radio, 215–216
 Internet service provider (ISP), 129
 ISP e-mail accounts, 129–130
 iTunes Agent, 211

• J •

JPEG images, 183

• K •

keyboard(s), 57. *See also* sliding keyboard
 adjusting, 293
 arrow keys, 320
 Multi-Touch, 50–56, 58, 293
 onscreen, 22–23, 50
 suggestions, 293, 320–321
 Swype, 50
 types, 50
 Keyword tag, 199
 Kobo, 226

• L •

labels (Gmail), 132
 landscape orientation
 activating, with sliding keyboard, 38, 40
 advantages of, 320
 changing from portrait to, 37
 changing Home screen to, 40
 and sliding keyboard, 17
 troubleshooting for, 308
 Laputa, 226
 Launcher
 on Dock, 284
 location on Home screen, 39
 replacing, 287
 layers (Maps app), 169–170
 library
 Kindle, 228
 music, 206–207
 photo albums, 195–196
 license agreement, 236
 Light On, 191
 LinkedIn, 163
 links
 in other open windows, 148
 selecting on web pages, 145
 in text messages, 119
 YouTube, 204
 Linux operating system, 26
 List view (bookmarks), 148
 live wallpaper
 changing Home screen to, 282
 touching Home screen with, 40
 traditional versus, 282–283
 location. *See also* Maps app
 activating, 171
 of contacts, 101, 176
 disabling location services, 154
 finding where you are, 171–173
 of images, 199
 in Maps app, 168, 170
 of pictures, 183, 186–187
 sending to others, 173
 Location Consent screen, 23
 locks, 287–288. *See also* Power Lock button

long-press technique
 activating Swype with, 50
 on Home screen, 282
 manipulating touchscreen with, 35
lost phone, finding, 317

• M •

main microphone, 15
maintenance
 backup, 302–303
 battery, 295–301
 cleaning, 302
 updating system, 303–304
manual delete (e-mail), 140–141
manual sync, 264–266
Maps app
 activating locations, 171
 adding contacts, 106–107, 175
 adding layers, 169–170
 businesses, restaurants, or points of interest, 174–175
 directions, 176–177
 finding out where you are, 171–173
 locating contacts, 176
 locating displayed contacts, 101
 navigating, 177–178
 navigation shortcut on Home screen, 178–179
 overview, 167
 Places command, 175–176
 sending location to others, 173
 specific addresses, 174
 using, 168–169
Market app, 234
Maximum Battery Saver mode, 298
Me (preset in Contact list), 102
Me button (social networking), 158
Me tag, 199
media devices, connecting to, 267–269
Meebo, 163
megapixel (MP), 185
message subject (Gmail), 132
Messaging app
 deleting messages with, 141
 as universal message inbox, 132–133
micro-USB connector
 about, 260
 mini-USB versus, 14
microfiber cloth, 302
microphone
 on earphones, 17
 headset, 18
 main, 15, 17
 noise-canceling, 16
 turning off, 69
Microphone key, 63
MicroSD (memory storage) card
 capacities of, 12
 defined, 11
 images stored on, 183
 installing, 11–12
 recommendation for, 3, 266
Microsoft Live mail, 128
Microsoft Office document
 attachments, 138
Mirror On Display app, 268
missed calls
 dealing with, 78
 and voice mail, 91
MMS. *See* multimedia message
mobile wireless hotspot, 252
Month view (Calendar), 218–220
Most Visited tab (web browsing), 147
MOTOPRINT, 257
Motorola, 50, 301
Motorola Terms of Service agreement, 22
Move to Media Area button, 241
Move to Phone button, 241
movies
 renting, 230–231
 viewing, 228–229
Movies app, 328
moving cursor, 58
MP (megapixel), 185
Multi-Touch keyboard
 special characters, 56
 suggestions, 58, 293
 on touchscreen, 50
 typing, 51–55
multimedia message (MMS)
 composing, 123–124
 overview, 122–123
 receiving, 125, 203
 video for, 189
Multimedia Station
 as accessory, 18
 storing phone in, 20

multiple windows (web browsing), 148

music

- adding from a computer, 209–211
- adding from Amazon MP3 store, 211–213
- browsing music library, 206–207
- creating playlists, 209, 214–215
- deleting, 215
- Internet radio, 215–216
- organizing, 213–215
- overview, 205
- playing, 207–209
- reviewing playlists, 213–214
- as ringtone, 88–89
- in Sleep mode, 26
- troubleshooting, 305

Music app, 268

Music Headquarters app, 206

music library, 206–207

mute

- doodle button as, 17
- and Mute icon, 70
- for phone calls, 69–70
- for video recording, 188

MyBookmarks app, 148

MySpace, 163



Name Card option, 124

navigation

- Calendar app, 220
- shortcut on Home screen, 178–179

Navigation (Maps app)

- and battery performance, 321
- using, 177–178

network

- digital, 248
- Wi-Fi, 248–251

Network icon, 72

Network Lost Tone, 292

New Window, 148

News Feed (Facebook), 162

Next key

- function of, 52
- on Multi-Touch keyboard, 51

Nighttime Saver mode, 298

noise-canceling microphone, 16

Normal Video, 190

notification light, 15

notifications

- of alarms set, 225
 - dismissing, 44
 - Download, 151
 - e-mail, 131
 - event, 223
 - Google Voice, 96–97
 - Home screen, 38
 - hotspot, 252
 - icons for, 42, 44
 - low battery, 297
 - missed calls, 78
 - of music playing, 208
 - New Text Message, 121
 - reviewing, 42–44
 - social networking, 158–159
 - when turning on phone, 25
- Nova game app, 231
- Now Playing option (music library), 207
- number keys
- on alternative keyboard, 52
 - on Multi-Touch keyboard, 51



offensive words

- disabling censorship of, 315
- and voice censor, 64

online photo album, 197

onscreen keyboard

- Done key, 23
- in setup process, 22

operating system

- Android, 26, 149–150, 303, 318, 329
- Linux, 26
- updating, 303–304

optical zoom, 183



opting out (texting), 124

orientation, 37–38

- camera, 183
 - landscape, 17, 37–38, 40, 308, 320
 - options for, 37
 - of pictures, 200–201
 - portrait, 37–38
 - troubleshooting, 308
 - for web pages, 153
- overheating, 308



- packaging contents, 10–11
- pan (Maps app), 169
- Pandora Radio app
 - function of, 215
 - StreamFurious versus, 216
- panel indicator, 40
- Paperclip icon (e-mail), 138
- password
 - appearance of, 23
 - assigning, 290–291
 - e-mail, 130
 - Gmail, 128
 - Google account, 29
 - social networking sites, 157
 - typing, 54
 - Wi-Fi network, 250
- password unlock screen, 25
- pasting text, 61–62
- pattern lock
 - as security feature, 23
 - unlocking, 24
 - using, 288–290
- pause, adding (to phone number), 71
- paying for apps, 237
- PC mode (USB connection), 261
- Performance mode (battery), 298
- personalization
 - accessibility settings, 294
 - adding apps to Dock, 284
 - adding apps to Home screen, 284
 - assigning password, 290–291
 - AutoAnswer, 291–292
 - AutoRetry, 291–292
 - creating shortcuts, 285–286
 - creating unlock pattern, 288–290
 - Double Tap Home Launch function, 293
 - Home screen, 282–287
 - icons and widgets, 286–287
 - overview, 281
 - ringtone, 89
 - screen locks, 287–288
 - security, 287–291
 - setting changes, 292–293
 - setting PIN, 290
 - silencing features, 291
 - wallpaper, 282–283
 - widgets, 285
- Perspective view (Maps app), 169
- phone information, finding, 303
- phone numbers
 - adding for exiting contacts, 104
 - adding pause prompt to, 71
 - default, 109
 - international, 275–276
 - sending text messages to, 121
 - in text message, 119
- phone status, 38
- photo album
 - Camera Roll, 194–195
 - creating, 196–197
 - cropping images, 200
 - deleting images, 202
 - editing pictures, 200–202
 - Facebook, 162
 - finding image location on map, 199
 - Gallery app, 194
 - overview, 193
 - printing pictures, 200
 - rotating pictures, 200–201
 - setting images for contacts or as wallpaper, 201–202
 - sharing, 202–204
 - tagging images, 197–199
 - uploading video to YouTube, 204
 - viewing albums, 195–196
- photo-editing software, 200
- Photos (Facebook), 162
- Picasa photo-sharing site, 203
- picture(s). *See also* photo album
 - adjusting camera, 187
 - changing resolution, 184–185
 - of contacts, 109, 322–323
 - deleting, 183–184
 - in e-mail messages, 138
 - with Facebook app, 162
 - image location, 183, 186–187
 - panorama shots, 185–185
 - printing, 200
 - self-portrait, 185
 - sharing, 202–204
 - for social networking sites, 160–161
 - taking, 182–183

- PIN
 - setting a, 290
 - unlocking phone with, 25
 - PIN lock
 - defined, 290
 - disabling, 288
 - pinch technique, 35
 - Places command (Maps app), 175–176
 - placing calls, 68–71
 - conference calls, 84–85
 - direct-dial shortcuts, 316
 - overview, 68–71
 - speed dial, 82
 - plastic cling sheets, 10
 - playing music, 207–209
 - playlist
 - creating, 209, 214–215
 - defined, 213
 - removing/deleting songs, 215
 - reviewing, 213–214
 - Playlists option (music library), 206
 - + (plus) character
 - in international phone numbers, 276
 - replacing country code with, 276, 322
 - points of interest, finding, 174–175
 - POP mail server, 130
 - pop-up blocking, 153
 - portrait orientation
 - applications fixed in, 38
 - changing from landscape to, 37–38
 - Postcard icon, 176
 - power connector, 15
 - power consumption
 - determining, 297–298
 - largest sources of, 321
 - managing, 298–299
 - Navigation mode, 178
 - Power Control widget
 - activating Wi-Fi radio with, 249
 - turning on Bluetooth with, 254
 - Power Lock button
 - location of, 15–16, 21
 - overview, 21
 - for Silent mode, 36
 - snooze mode, 29
 - touchscreen enabled by, 20
 - turning off phone, 31
 - turning on phone, 21, 23–24
 - waking phone with, 26
 - while on a call, 319–320
 - preinstalled software, 241
 - press-and-hold, 57
 - primary unlock screen, 23
 - Print to Retail
 - function of, 203
 - sharing documents with, 258
 - printing
 - pictures, 200
 - wireless, 255–258
 - privacy options
 - location technology, 170
 - web browsing, 153–154
 - Profile (Facebook), 162
 - program. *See* apps (applications)
 - proximity sensor
 - and making phone calls, 70
 - and touchscreen, 20
 - punctuation marks, dictating, 63
-  •
- Quick Actions, 314
 - Quick Launch, 311–312
 - QVGA setting (video quality), 189
 - QWERTY keyboard, 50
-  •
- radio
 - Internet, 215–216
 - Wi-Fi, 249
 - ratings (apps), 235
 - reading e-mail messages, 133–135
 - rearranging icons and widgets, 286–287
 - receiving calls
 - overview, 74–76
 - in Sleep mode, 26, 31
 - when on another call, 83–84
 - receiving text messages, 121
 - Recent Calls list
 - adding contacts from, 103–104
 - adding speed-dial number from, 82
 - dialing numbers from, 73–74
 - using, 79–80

- recently used apps, 47
- recording video, 187–189
- refunds for apps, 238
- Remember Form Data, 154
- reminder icon, 5
- reminders, setting or dismissing, 222
- remove
 - apps, 240–241
 - contacts, 112–113
 - contacts from group, 112
 - events, 222–223
 - icons and widgets, 286–287
 - lock, 288
 - navigation route, 178
 - social networking account, 157
 - songs from playlist, 215
- renting movies, 230–231
- Repeat button (music)
 - icons for, 208
 - and playing music, 207
- replacing battery, 301
- reply
 - e-mail, 122, 134–135
 - text message, 76–77
- Reply All (e-mail), 134
- resolution
 - pictures, 184
 - video, 188–189
- restaurants, finding, 174–175
- retrieving messages
 - carrier voice mail, 92–93
 - e-mail, 131
 - Google Voice, 96–97
 - visual voice mail, 94
- Return key
 - on Multi-Touch keyboard, 51
 - on sliding keyboard, 53
- review
 - calls, 79–80
 - downloaded apps, 238–239, 241–242
 - downloaded information, 152
 - most recently used apps, 47
 - notifications, 42–44
 - playlists, 213–214
 - schedule, 220–221
- ringer volume, 292

- ringtone
 - choosing, 87–88
 - creating, 89
 - defined, 76
 - music as, 88–89
 - setting, 88
- roaming
 - checking for, 321
 - deactivating, 301
 - icon for, 72
 - surcharges for, 271–272
- roaming surcharges, 272
- root folder, 266
- rooting, 241
- rotate
 - image, 200–201
 - Maps app, 169
 - on touchscreen, 35
- Route Info (Maps app), 178



- Satellite view (Maps app), 169
- Scenes adjustment (camera), 187
- schedule, 220–221. *See also* Calendar app
- screen locks, 287–288
- Screen Timeout, 292
- scrolling
 - in Contacts list, 100
 - in Maps app, 169
- search
 - Android Market, 234
 - contacts, 103
 - Gmail messages, 132
 - Maps app, 173–175
 - web, 148–149
 - YouTube videos, 228
- Search command, 323
- Search key, 53
- security
 - assigning password, 290–291
 - creating unlock pattern, 288–290
 - customizing, 287–291
 - screen locks, 287–288
 - setting PIN, 290
 - web browsing options, 153–154

- Security Lock Timer, 288
- selecting text, 59–61
- self-portraits, 185
- self-video recordings, 190
- sender (Gmail), 132
- setting status (social networking), 159–160
- settings, changing, 292–293
- setup, phone, 21–23
- share
 - apps, 239–240
 - contacts, 112
 - media items, 124
 - pictures and video, 160, 197, 202–204
 - with Print to Retail, 258
 - web pages, 149–150
 - wireless connection, 251–253
- Share button
 - on application's info screen, 242
 - location of, in Browser app, 145
 - using, for photos and videos, 202
- Share Media, 269
- Shared Folders, 267
- Shift key
 - and appearance of cursor, 55
 - on Multi-Touch keyboard, 51
 - on sliding keyboard, 53
- Shift Lock light, 16
- shortcuts
 - for apps, 47, 237
 - to bookmarks, 147
 - creating, 285–286
 - direct-dial, 316
 - navigation, 178–179
 - with sliding keyboard, 312–313
 - for test messaging, 316
- Show alphabetic keyboard, 52
- Show alternative keyboard, 52
- Show numbers or symbols keyboard, 51
- Shuffle button (music)
 - icons for, 208
 - and playing music, 207
- Sign In button, 23
- signal strength
 - icon for, 72
 - and making phone calls, 71
 - of Wi-Fi network, 251
- signature, e-mail
 - creating, 139–140
 - reason for including, 54
- silencing phone
 - methods of, 36
 - with Silent mode, 291
- Silent mode
 - activating, 36
 - entering, 291
- SIM card
 - location of, 12
 - using, 13
- Skype Mobile
 - about, 126
 - making international calls with, 276–279
 - text messages versus, 118
- sleep, 26
 - options, 29
 - Sleep mode, 26, 30–31
 - snooze mode, 29–30
- Sleep mode
 - about, 26
 - activating, 30–31
- Slideshow option, 124
- sliding keyboard
 - arrow keys, 320
 - features, 53
 - location, 15
 - menu shortcuts, 312–313
 - overview, 15–17
 - and soft buttons, 35
 - special characters, 57
 - suggestions, 58
 - text selection, 60
 - typing, 54–57
- snooze mode, 29–30
- social networking
 - adding accounts, 156
 - with displayed contacts, 101
 - Facebook app, 161–162
 - managing accounts, 157
 - overview, 155
 - popular sites, 163
 - setting status, 159–160
 - Social Networking app, 155–161
 - status updates, 156–157, 160
 - Twitter app, 162–163
 - uploading picture, 160–161
- Social Networking app
 - adding accounts, 156
 - managing accounts, 157
 - overview, 155

- setting status, 159–160
 - status updates, 158–159
 - uploading picture, 160
 - Social Networking widget, 160
 - soft buttons
 - functions of, 17
 - location of, 15, 17
 - using, 34–35
 - software, resetting, 306–307. *See also* apps (applications)
 - Songs option (music library), 206
 - Space key
 - and automatic placement of period, 54
 - on Multi-Touch keyboard, 51
 - spam, 124
 - speaker(s), 16
 - Speaker button
 - function of, 70
 - location, 15
 - location of, 69
 - for phone calls, 69–70
 - in setup process, 22
 - special characters, accessing, 56–57
 - speed dial, 82
 - SportsTap app, 328
 - spread technique, 35
 - SSID, 251
 - Star icon (Gmail)
 - on e-mail message, 134
 - in Gmail inbox, 132
 - Start Block marker, 59
 - starting apps. *See also individual apps*
 - from App menu, 45–46
 - from Home screen, 44
 - status
 - battery, 297–298
 - social networking, 159–160, 162
 - status bar, 38
 - status updates (social networking), 158–159
 - Stay Awake, 292
 - Stop button (web browsing), 145
 - storage (information)
 - accessing, 322
 - of apps, 242
 - apps for, 266–267
 - images, 151, 183
 - music, 207, 211
 - places for, 266
 - troubleshooting, 306
 - video recordings, 189
 - storing phone, 18–20
 - streamed video, 230
 - StreamFurious app, 216
 - StreamFurious Pro, 216
 - street addresses
 - finding, for your location, 171
 - looking for, 174
 - Street View (Maps app), 173
 - suggestions
 - activating setting for, 320–321
 - choosing, while typing, 58
 - sunlight, 20
 - swipe technique, 35
 - Switch Calls button, 84
 - Swype keyboard, 50
 - symbols
 - accessing, 55–57
 - on Multi-Touch keyboard, 52
 - on sliding keyboard, 53
 - Symbols keyboard, 52
 - syncing (synchronizing)
 - automatic, 300
 - with doubleTwist, 211, 263–264
 - with Google account, 27
 - Google Books, 226–227
 - manual, 264–266
 - music, 209–211
 - with other accounts, 29
 - overview, 262
- T •
- Tab key, 53
 - tag, 197
 - tagging images, 197–198
 - Talk app, 126
 - Task Manager, 317–318
 - tech support (Verizon), 307
 - technical information icon, 5
 - Terms of Service agreement, 22
 - Terrain view (Maps app), 169
 - tethering feature
 - about, 251
 - using, 253

- text
 - adjusting size of, 153
 - e-mail, 136
 - finding on web pages, 149
 - selecting, 59–61
- text editing
 - copy and paste, 61–62
 - cutting, 61–62
 - moving cursor, 58
 - selecting text, 59–61
 - of voice-input text, 63
- Text Message Reply, 76–77
- text messages (texting)
 - abbreviations for, 120
 - alternatives to, 126
 - attaching media, 203
 - attaching video, 191
 - composing, 118–119
 - creating shortcut for, 316
 - deleting, 125
 - to displayed contacts, 101
 - e-mail versus, 122
 - forwarding, 121–122
 - international, 274
 - multimedia, 122–125
 - opting out, 124
 - overview, 117–118
 - receiving, 121
 - sending to phone numbers, 121
- Text Messaging app, 284
- 3G (third generation) network
 - about, 248
 - mobile hotspots in, 252
- Thumbnail view (bookmarks), 148
- timer, 224–225
- tips icon, 5
- touch technique, 35
- touchscreen
 - cleaning, 302
 - defined, 2
 - disabling, 20
 - incoming call info on, 74–75
 - keyboards on, 50
 - location of, 15
 - manipulating, 35–36
 - overview, 17
 - in Sleep mode, 26
 - text selection on, 59
 - troubleshooting, 307–308
- troubleshooting, 304–308
- turning off, 31
- turning on
 - after first time, 23–25
 - and battery, 22
 - for first time, 14, 22–23
 - Power Lock button, 21
- tweet, 163
- Twitter
 - posting messages, 163
 - purpose of, 162
 - signing in, 163
 - status, 159
 - updates, 158
- Twitter app
 - on menu for sharing, 203
 - using, 162–163
- typing
 - accessing special characters, 56–57
 - guidelines, 54–56
 - Multi-Touch keyboard, 54–56
 - phone numbers to call, 68–69
 - sliding keyboard, 54–57
 - suggestions, 58, 320–321
 - Swype keyboard, 50
 - text messages, 118–119



- Uninstall button, 241
- uninstalling apps, 241
- Universal Inbox, 132–133
- unlock pattern, 288–290
- unlocking screen(s)
 - password, 25
 - pattern lock, 23–24
 - primary, 23
- unread message indication (Gmail), 132
- update
 - apps, 240
 - operating system, 303–304
 - password, 157
 - social networking, 156–157, 160
- upgrading, from Android phones, 12

- upload, 151
 - images, 160, 162–163
 - video to YouTube, 204, 229
 - USB cable
 - configuring, 260–261
 - connecting phone to computer, 260
 - disconnecting phone from computer, 262
 - overview, 259
 - USB Connection, 260–261
 - USB connector, 15
 - USB Mass Storage option (USB connection), 261
 - username, 130
- *V* •
- vCard files
 - importing contacts with, 105–106
 - in multimedia text messages, 124
 - Verizon
 - Backup Assistant app, 303
 - cellular service from, 3
 - customer service, 278
 - international calling, 275
 - location services, 171
 - tech support, 307
 - voice mail, 91–93
 - voice mail phone number, 92
 - voice-mail system commands, 93
 - VGA setting (video quality), 189
 - Vibration mode
 - activating, 36
 - adjusting, 291
 - and battery performance, 300
 - video. *See also* photo album
 - playing back, 194
 - recording, 187–189
 - renting movies, 230–231
 - setting quality, 189–190
 - sharing, 202–204
 - uploading to YouTube, 204
 - Video Message mode, 190–191
 - viewing, 228–229
 - Video Message, 190–191
 - Videos app, 230
 - viruses
 - avoiding, 329
 - and text messaging, 124
 - Visual Voice Mail, 92–94
 - Voice app, 96
 - voice input
 - activating, 52
 - sensor feature, 64
 - commands, 63–64
 - dictating to phone, 62–63
 - voice mail
 - carrier, 91–93
 - Google Voice, 94–97
 - retrieving messages, 92–94, 96–97
 - sending calls to, 84, 86–87
 - Visual, 93–94
 - voice navigation, 177–178
 - Voice Recorder app, 329
 - volume
 - incoming call signal, 77–78
 - ringer, 292
 - setting, 18, 36
 - volume (storage), 267
 - volume control
 - location of, 15, 17
 - music, 209
- *W* •
- waking phone
 - methods of, 26
 - with sliding keyboard, 17
 - wallpaper
 - from Android Market, 235
 - changing, 282–283
 - live wallpaper feature, 40
 - setting image for, 201–202
 - Warhol, Andy, 228
 - warning icon, 5
 - warranty, 10
 - web-based e-mail accounts, 128–129
 - web browsing
 - bookmarks, 146–148
 - changing appearance, 153
 - downloading, 150–152

web browsing (*continued*)
 getting to web pages, 144–145
 managing multiple windows, 148
 moving back and forward, 146
 overview, 143–144
 privacy and security options, 153–154
 searching, 148–149
 selecting links, 145

web pages
 changing appearance, 153
 getting to, 144–145
 home, 144–145, 152–153
 reloading, 145
 selecting links, 145
 sharing, 149–150
 stop loading, 145
 switching between, 148
 text selection on, 61
 viewing, 144

Week view (Calendar), 218–220

What's Nearby command (Maps app), 173

Wi-Fi
 accessing, 250–251
 activating, 249
 Android Market downloading, 234
 location information, 171
 power consumed by, 321
 turning off, 300
 understanding, 248
 for web browsing, 143
 when roaming, 272

Wi-Fi radio, 249

widgets. *See also specific widgets*
 adding, 285
 from Android Market, 235
 Home screen, 39
 rearranging and removing, 286–287
 using, 45

window mount, 19

Windows Media Player
 synchronizing music with, 209–211
 and Windows Media Sync USB option, 261

Windows Media Sync option (USB connection), 261

wireless connection. *See also* Bluetooth;
 Wi-Fi
 in airplanes, 274
 creating mobile hotspot, 252
 digital network, 248
 overview, 247
 printing, 255–258
 sharing, 251–253
 tethering feature, 251, 253



Yahoo! Mail
 and Email app, 128
 New Mail notification icon, 131

YouTube
 sharing option, 203
 uploading video to, 204
 viewing videos on, 228–229

YouTube app
 sharing option for, 204
 viewing videos with, 228–229



Zedge app
 about, 329
 ringtones from, 89
 wallpaper features of, 283

zoom function, 17
 Camera app, 183
 Maps app, 169, 175
 video recording, 188